

# Inmarsat Fleet and Swift Land Earth Station Operators and Access Codes

05.01.07

## Inmarsat Fleet F77

Land Earth Station Operator	Country	Ocean Region			
		AOR-E	AOR-W	IOR	POR
Beijing MCN	China	868	868	868	868
France Telecom	France	011	011	011	011
KDDI	Japan	003	003	003	003
Korea Telecom	South Korea	006	006	006	006
Malaysia Telecom (Virtual)	Malaysia	060	060	060	060
Ministere des Posts et Telecommunications	Algeria	777			
OTE	Greece	005	005	005	005
Singapore Telecom	Singapore	210	210	210	210
Stratos Global (Goonhilly LES)	UK	002			
Stratos Global (Borum LES)	Netherlands		002	002	
Stratos Global (Auckland LES)	New Zealand				002
Stratos Global (Borum LES)	Netherlands	012	012	012	012
Stratos Global (Perth LES)	Australia			022	
Telecom Italia	Italia	555	555	555	555
Telenor Satellite Services AS	Norway	004	004	004	004
Telenor Satellite Services Inc.	USA	001	001	001/405	001
VSNL	India			306	

## Inmarsat Fleet F77 128kbps Data

Land Earth Station Operator	Country	Ocean Region			
		AOR-E	AOR-W	IOR	POR
Beijing MCN	China			868	868
France Telecom	France	011	011	011	011
KDDI	Japan	003	003	003	003
Korea Telecom	South Korea			006	006
Stratos Global (Goonhilly LES)	UK	002			
Stratos Global (Borum LES)	Netherlands		002	002	
Stratos Global (Auckland LES)	New Zealand				002
Stratos Global (Borum LES)	Netherlands	012	012	012	012
Stratos Global (Perth LES)	Australia			022	
Telecom Italia	Italia	555	555	555	
Telenor Satellite Services AS	Norway	004	004	004	004
Telenor Satellite Services Inc.	USA	001	001	001/405	001

## Inmarsat Fleet F55

Land Earth Station Operator	Country	Ocean Region			
		AOR-E	AOR-W	IOR	POR
Beijing MCN	China	868	868	868	868
France Telecom	France	011	011	011	011
KDDI	Japan	003	003	003	003
Korea Telecom	South Korea			006	006
OTE	Greece	005	005	005	005
Telenor Satellite Services AS	Norway	004	004	004	004
Telenor Satellite Services Inc.	USA	001	001	001/405	001
Stratos Global (Goonhilly LES)	UK	002			
Stratos Global (Borum LES)	Netherlands		002	002	
Stratos Global (Auckland LES)	New Zealand				002
Stratos Global (Borum LES)	Netherlands	012	012	012	
Stratos Global (Perth LES)	Australia				012
Telecom Italia	Italy	555	555	555	
VSNL	India			306	

### Inmarsat Fleet F33

Land Earth Station Operator	Country	Ocean Region			
		AOR-E	AOR-W	IOR	POR
Beijing MCN	China			868	868
France Telecom	France	011	011	011	011
KDDI	Japan	003	003	003	003
Korea Telecom	South Korea			006	006
OTE	Greece	005	005	005	005
Telenor Satellite Services AS	Norway	004	004	004	004
Telenor Satellite Services Inc.	USA	001	001	001	001
Stratos Global (Goonhilly LES)	UK	002			
Stratos Global (Borum LES)	Netherlands		002	002	
Stratos Global (Auckland LES)	New Zealand				002
Stratos Global (Borum LES)	Netherlands	012	012	012	
Stratos Global (Perth LES)	Australia				012
Telecom Italia	Italy	555	555	555	
VSNL	India			306	

### Inmarsat Swift 64

Land Earth Station Operator	Country	Ocean Region			
		AOR-E	AOR-W	IOR	POR
Telenor Satellite Services AS	Norway	004	004	004	004
Telenor Satellite Services Inc.	USA	001	001	001/405	001
Stratos Global (Goonhilly LES)	UK	002			
Stratos Global (Borum LES)	Netherlands		002	002	
Stratos Global (Auckland LES)	New Zealand				002
Stratos Global (Borum LES)	Netherlands	012	012	012	012
Stratos Global (Perth LES)	Australia	222	222	022/222	022/222
Telecom Italia	Italy	555	555	555	